



Cockpit overview



- ① **Door handle**
 Locks the vehicle centrally
 Unlocks the vehicle centrally
- ② **Seat functions**
 Adjusts the seats electrically
 Memory function and presets
 1 2 3
- ③ Switches the seat heating on/off
 Switches the seat ventilation on/off
- ④ Light switch
 Rear fog lamp
- ⑤ Head-up Display
- ⑥ Multifunction steering wheel control panels
- ⑦ Multifunction display
- ⑧ DIRECT SELECT lever
- ⑨ Media display of the MBUX multimedia system
- ⑩ Climate control system control panel
- ⑪ Hazard warning lamps

WARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Cockpit overview

- ⑫ **MBUX multimedia system touchpad**
 Back button
 Press: Audio control menu
 Swipe: next/previous track or radio station
 Displays the home screen
- ⑬ **Buttons on the right of the touchpad**
 Adjusts the volume
 Press briefly: mute function
 Press and hold: switches off the MBUX multimedia system
 Calls up navigation
 Calls up radio or media
 Calls up the telephone

- ⑭ **Buttons on the left of the touchpad**
 DYNAMIC SELECT
 Active Parking Assist
 Calls up vehicle functions (e.g. assistance systems)
 Favorites button
 Press and hold: adds a favorite
- ⑮ Start/stop button for starting/stopping the engine
 Button for the ECO start/stop function
 The ECO start/stop function cannot be permanently deactivated.
- ⑯ Instrument cluster lighting
- ⑰ Electric parking brake
- ⑱ Opens or closes the tailgate
- ⑲ Door control panel with controls for power windows, exterior mirror settings and the override feature for the rear side windows
 If the front passenger mirror is selected and you engage reverse gear, the front passenger mirror moves into the stored parking position.




- Overhead control panel**
- ① Buttons for interior lighting and reading lights
 - ② Button for Mercedes me connect*
 - ③ SOS button* (Mercedes-Benz emergency call system)
 - ④ Opens/closes the sliding sunroof Roller sunblind
- * Not available in all countries

Note that your vehicle may not be equipped with all features described.

Operating elements on the steering wheel and Active Distance Assist DISTRONIC



- ① Wipes the windshield once
Wipes with washer fluid
- ② Sets the windshield wipers
Off, normal/frequent interval wiping, slow/fast continuous wiping
- ③ Turn signal, left/right
- ④ High-beam flasher
- ⑤ Adaptive Highbeam Assist Plus
- ⑥ Switches the steering wheel heater on/off
- ⑦ Adjusts the steering wheel



- Active Distance Assist DISTRONIC**
- ① Switches on or off Active Distance Assist DISTRONIC
 - ③ Active Distance Assist
 Activates DISTRONIC with current speed
 - ④ Activates with the stored speed/pulls away with Active Distance Assist DISTRONIC
 - Deactivates Active Distance Assist DISTRONIC

Changing the speed/distance

- ② Reduces the specified minimum distance
 Increases the specified minimum distance
- ③ Increases the speed
 Decreases the speed

Active Distance Assist DISTRONIC maintains a stored speed.
The lowest speed that can be set is 12 mph (20 km/h).

You can change the set speed:

- ▶ **1 mph increment (1 km/h):** Briefly press rocker switch ③ up or down.
- ▶ **5 mph increment (10 km/h):** Press rocker switch ③ up or down past the point of resistance.

Using rocker switch ②, you can change the specified minimum distance to the vehicle in front. The specified minimum distance depends on the currently driven speed.

WARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Climate control



Operating options
You can adjust climate control using the buttons on climate control panel ①.
If you change any settings, media display ② briefly shows the current settings of the climate control system.

- Air conditioning control panel**
- Sets the temperature
 - Sets the air distribution
 - Calls up the air conditioning menu
 If you press and hold the button for approximately 4 seconds, climate control will be reset to the basic settings.
 - Sets the air flow, switches climate control off completely
 - Sets climate control to automatic
 - Defrosts the windshield
 - Defrosts the rear window
 - Cooling with air dehumidification
Residual heat with the engine off
 - Synchronized operation of all zones
 - Air-recirculation mode
The air in the interior is recirculated; the windows may mist up more quickly.

- General notes**
- Optimum climate control is only achieved with the side windows and roof closed.
To prevent the windows from fogging up, please observe the following information:
- Switch on the cooling function.
In warm weather, the air inside the vehicle will be cooled. This function also dries the air inside the vehicle.
 - As far as possible, do not switch off climate control
 - Switch on air-recirculation mode only briefly
 - If necessary, briefly switch on the windshield defroster function

Note that your vehicle may not be equipped with all features described.

Buttons on the multifunction steering wheel



- Operating the multifunction display and Head-up Display**
- ① Back/Hold button
 Press and hold: shows the standard display (speedometer, trip meter and rev counter)
 - ② Touch Control for multifunction display and Head-up Display
 Press: Display your selection

- Operating the MBUX multimedia system**
- ③ Home screen
 - ④ Touch Control for the MBUX multimedia system
 Press: confirm your selection
 - ⑤ Back button
 Ends a dialog with the Voice Control System

- ⑥ Accepts a telephone call
 Rejects a telephone call
 Ends a call
 Ends a dialog with the Voice Control System
- ⑦ Adjusts the volume
 Press: switches sound on or off
- ⑧ Starts a dialog with the Voice Control System
 Press and hold: activates the voice control system of the mobile end device currently connected
- Display favorites

Multifunction display



WARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Overview

The multifunction display is broken down into three areas. Content ④ can be freely selected. Content ⑤ can be set using menu bar ③.

Operating the menu bar

- ▶ **To call up the menu bar:** Press button ①.
- ❶ If you press and hold button ①, the standard display of the multifunction display is shown.
- ▶ **To select content:** Use Touch Control ② to make swiping movements and then press to confirm the menu.

Setting the multifunction display

- ▶ Swipe to the left or right on Touch Control ②. The selected area will be highlighted.
 - ▶ On Touch Control ②, swipe up or down in order to select the desired display content.
- Index points ⑥ show the selected display content.


Head-up Display



Activating the Head-up Display

The Head-up Display is activated via the menu bar of multifunction display ①.

- ▶ Using Touch Control, make upward swiping movements. The cursor will move up into the Head-up Display.



Operating the Head-up Display

The Head-up Display has three configurable areas. You can individually adapt the content of these areas or leave them empty.

- ▶ Use Touch Control ⑥ to make swiping movements and then press to confirm the menu.


Quit the Head-up Display

- ▶ Press Back/Home button ①.
- or
- ▶ Wait until the cursor moves back into the multifunction display.

- ① Back/Home button
- ② Current cursor position, shown by means of blue highlighting
- ③ Index point of the selected content
- ④ Switches off the Head-up Display
- ⑤ Adjusts the Head-up Display (contrast/brightness/position)
- ⑥ Touch Control

Note that your vehicle may not be equipped with all features described.

MBUX multimedia system home screen



- ① Main applications
- ② Quick-access (e.g. direct destination entry or navigating home)
- ③ Global search (search for functions in the system, e.g. Music or Navigation, as well as those external to the system, e.g. Internet)
- ④ Creates, modifies and switches profiles. You can, for example, store the seat and steering wheel position, multifunction display contents, ambient lighting settings, favorites and personalized suggestions.
- ⑤ Calls up the Notifications Center
- ⑥ Number of applications and the currently selected display area
- ⑦ Calls up the air conditioning menu
- ⑧ Calls up favorites/suggestions and themes

WARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

The Voice Control System (voice control system for infotainment, navigation and vehicle functions)

Starting a dialog

For the dialog with the Voice Control System you can use complete sentences as voice commands.

- ▶ **Activation with a keyword:** Say "Hi Mercedes" and combine it with a voice command or a question.
- or
- ▶ **Activation using the rocker switch on the multifunction steering wheel:** Press up and after the acoustic signal say a voice command or a question.

Help functions

- **Optimal operation:** say the "Help Voice Control System" voice command.
- **Help for the current function:** Say the "Help" voice command during the dialog.
- **Help for a specific system:** Say the voice command for the desired system, e.g. "Help telephone".

You can change the language via the system language settings. If the set system language is not supported by the Voice Control System, English will be selected.

Selected examples

Navigation voice commands

- "Navigate to 25 Woodward Avenue, Detroit" Starts route guidance to an address. The order of the road, town or street number is irrelevant.
- "Navigate to John Doe" Starts route guidance to a contact from your address book.
- "Show alternative routes" The navigation shows alternative routes for route guidance.
- "Navigate to the nearest gas station." Starts route guidance to the nearest filling station.

Telephone voice commands

- "Call John Doe" The telephone number of a stored contact is dialed.
- "Read out new text messages" All new text messages will be read out.
- "Call my father on his cell number." The telephone number of the contact "Father cell" will be called.

Media/radio voice commands

- "Switch to station Z100" If you are listening to the radio, you can say the name of a station to which you would like to listen.
- "Play Bob Dylan" The system searches through the names of all available albums, tracks, artists, music genres and playlists. If the result is clear, playback starts immediately.

Vehicle voice commands

- "Open the Assistance menu"
- "Temperature 22 °C"
- "When is the next service due?"
- "Front passenger reading light on"
- "Ambient lighting to blue"
- "Head-up Display on/off"

Online voice commands

- ❶ To use this feature, you must have a connection to the Internet.
- "What will the weather be like tomorrow in Boston?"
- "Is it going to rain at my destination?"

Note that your vehicle may not be equipped with all features described.

Bluetooth® connection and external media sources



- ① Switches mobile phones
- ② Device manager

Connecting a mobile phone

Prerequisites

Bluetooth® is switched on on the mobile phone and the device is visible for other devices (see the manufacturer's operating instructions).

- ▶ On the MBUX multimedia system, select ▶ **Phone** ▶ .

Searching for a mobile phone

- ▶ Select **Connect New Device**.
 - ▶ Select the desired mobile phone.
- If your mobile phone is not found, try searching on the mobile phone itself.

Authorizing a mobile phone

- ▶ A code is displayed in the multimedia system and on the mobile phone.
- ▶ **If the codes match:** confirm the code on the mobile phone.

Further information

Detailed information on Bluetooth® connections with your mobile phone can be found at:

www.mercedes-benz.com/connect



Connecting external media sources

- ① USB connection (type C)
- ② USB connection for Apple CarPlay™ or Android Auto™

Depending on the vehicle's equipment, additional USB ports can be found in the stowage compartment of the front center console or in the rear folding compartment.

WARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Further information on your vehicle



HANDS-FREE ACCESS

If you carry the KEYLESS-GO key on your person, you will be detected by a sensor. Do not touch the bumper and maintain a distance of around 30 cm.

- ▶ **To open or close:** Kick into sensor detection range under the bumper with your foot.
- ❶ The kicking movement must be towards the vehicle and back again, and it must not be carried out too slowly.



Deactivating the KEYLESS-GO key function

If you wish to reduce the energy consumption of the SmartKey, you can deactivate the KEYLESS-GO function.

- ▶ **To deactivate:** Press twice in succession on button ①. The battery check lamp of the SmartKey lights up twice briefly and once for a longer period.
- ▶ **To activate:** Press any button on the SmartKey.

Further information

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

<http://www.mbusa.com>

Mercedes-Benz Guides app

The Mercedes-Benz Guides app contains the complete Operator's Manual and is available free-of-charge in the familiar app stores.



How-to videos



Operator's Manuals

Registering in the Mercedes me portal

Register in the Mercedes me portal in order to be able to use the full scope of your vehicle's functions.



Note that your vehicle may not be equipped with all features described.